

Split Repair Boots Product #	A	B	C	D	Ounces DBB IV Bonder or DRP Paste	Ounces DBB III Bonder	Ounces DBF II Fill
RB 8-0.9	0.910	3.000	6.435	5.282	2	1	
RB 8-1.1	1.200	3.000	6.435	5.282	2	1	
RB 8-1.4	1.370	3.000	6.435	5.282	2	1	12
RB 8-1.6	1.570	3.000	6.435	5.282	2	1	
RB 8-1.7	1.725	3.000	6.435	5.282	2	1	
RB 8-1.8	1.862	3.000	6.435	5.282	2	1	
RB 8-1.9	1.962	3.000	6.435	5.282	2	1	
RB 8-2.0	2.050	3.000	6.435	5.282	2	1	
RB 8-2.2	2.160	3.000	6.435	5.282	2	1	11
RB 8-2.4	2.425	3.000	6.435	5.282	2	1	8
RB 8-2.5	2.545	3.000	6.435	5.282	2	1	8
RB 8-2.7	2.735	3.000	6.435	5.282	2	1	7
RB 8-2.9	2.880	3.000	6.435	5.282	2	1	
RB 8-3.0	3.045	3.000	6.435	5.282	2	1	
RB 8-3.6	3.600	3.000	6.435	5.282	2	1	3
RB 8-UK	n/a	3.000	6.435	5.282	2	1	14

DBB III Bonder is used for:
Bonding split Fuel-Thane parts

DBB IV Bonder is used for:
Any part on Fiberglass sumps.

DRP Paste can be used for:
Any part attaching to Poly sumps.
Any Alcryn part on fiberglass sumps.

