

Split Repair Boot Interference Data

Minimum Space

Repair Boots	Between Centerlines	Boot I.D.	Pipe Sizes
RB 14 to Walls	7"	10.5"	4.5"
RB 14 to RB 14	13 1/2"	10.5"	
RB 12 to Walls	4 5/8"	6"	4.5" to 4.8" Ducted
RB 12 to RB 12	9 1/2"	6"	2", 3", 4" FRP
RB 12 to RB 10	8 7/8"	6"	2", 3", 4" LCX
RB 12 to RB 8	7 7/8"	6"	
RB 12 to RB 4	7"	6"	
RB 10 to Walls	4 1/4"	5 1/2"	2", 3", 4" FRP
RB 10 to RB 10	8 1/2"	5 1/2"	
RB 10 to RB 8	7 3/8"	5 1/2"	
RB 10 to RB 4	6 5/8"	5 1/2"	
RB 8 to Walls	3 1/4"	4"	2", 3" FRP & 2" LCX
RB 8 to RB 8	6 1/2"	4"	1 1/2", 2" Coaxial
RB 8 to RB 4	5 5/8"	4"	3/4, 1" Rigid Conduits
RB 4 to Walls	2 3/8"	2"	3/4, 1" Rigid Conduits
RB 4 to RB 4	4 3/4"	2"	